



It's used to communicate by RS485

Connector RJ45



RJ45	
1	\boldsymbol{A}
2	В
3	\boldsymbol{A}
4	RXD0
5	TXD0
6	В
7	Vcc
8	GND